

Technical Bulletin

No: 148 – Millenium A Telephone Bus Post Fader / Pre ON/OFF Modification

Requirement: Change normal mixing function of telephone bus from post fader/post off/on to **pre on/off** so that the telephone signal joins the telephone output bus whenever the telephone bus select switch is pushed and the fader is raised.

